

QS-III single-core splices: Installation in a few easy steps



1. Prepare cable and position 3M™ Cold Shrink QS-III Splice components



2. Unwind core



3. Re-jacket 3M Cold Shrink QS-III



Completed Splice